



AVAILABLE PARTS ARE:
 80365GS (GLASS SHADE)
 BULB13WPL (BULB)

INSTALLATION INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

CAUTION: TO AVOID POSSIBLE ELECTRIC SHOCK, MAKE SURE THE ELECTRICITY IS SHUT OFF AT THE MAIN PANEL. IF YOU ARE REPLACING AN EXISTING FIXTURE, FIRSTLY, TURN THE FIXTURE OFF. NEXT, TURN THE WALL SWITCH OFF. FINALLY, GO TO THE MAIN FUSE OR BREAKER BOX IN YOUR HOME. TURN THE FUSE OR BREAKER TO THE OFF POSITION. SOME TYPES OF FUSES MUST BE UNSCREWED TO SHUT OFF THE POWER.

* ALL WIRING MUST BE DONE IN ACCORDANCE WITH NATIONAL AND LOCAL ELECTRIC CODES.

** IF YOU DO NOT HAVE ELECTRICAL WIRING EXPERIENCE, HAVE YOUR FIXTURE INSTALLED BY A QUALIFIED LICENSED ELECTRICIAN.

*** THIS FIXTURE IS TO BE MOUNTED TO A UL LISTED OUTLET BOX CAPABLE OF SUPPORTING THE WEIGHT OF THIS FIXTURE.

THE OUTLET BOX MUST BE DIRECTLY SUPPORTED BY THE BUILDING STRUCTURE.

TOOLS: YOU WILL NEED THE FOLLOWING TOOLS OR EQUIPMENT: LADDER, SCREWDRIVER, PLIERS, ADJUSTABLE WRENCH.

UNPACK THE FIXTURE

YOU SHOULD HAVE RECEIVED THE FOLLOWING: CEILING PAN, NIPPLE, GLASS SHADE, BULB, METAL WASHER, (2) NUTS, FONT AND FINIAL.

MOUNTING HARDWARE PACK: CROSSBAR, (2) 8-32 x 1-1/4" SCREWS, (2) 8-32 x 2" SCREWS, (3) WIRE CONNECTORS, GREEN GROUND SCREW, TO PROTECT THE FINISH, PLACE ALL PARTS ON A SOFT SURFACE.



INSTALL THE FIXTURE

1. INSERT (2) 8-32 x 2" SCREWS INTO CROSSBAR TO LINE UP WITH HOLES IN CEILING PAN. ATTACH CROSSBAR TO OUTLET BOX USING TWO SCREWS PROVIDED WITH THE OUTLET BOX. (NOTE: IF THE SCREWS WITH THE OUTLET BOX ARE TOO SHORT, USE THE (2) 8-32 x 1-1/4" SCREWS PROVIDED IN THE MOUNTING HARDWARE PACKAGE).
2. CONNECT THE WHITE OR RIBBED FIXTURE WIRE TO THE WHITE SUPPLY WIRE IN THE OUTLET BOX USING THE TWIST-ON WIRE CONNECTOR PROVIDED. CONNECT THE BLACK OR SMOOTH FIXTURE WIRE TO THE BLACK SUPPLY WIRE IN THE SAME MANNER. INSTALL THE FIXTURE GROUND WIRE UNDER THE GREEN GROUND SCREW ON THE CROSSBAR THEN CONNECT THE FIXTURE GROUND WIRE TO THE SUPPLY GROUND WIRE IN THE OUTLET BOX USING THE TWIST-ON WIRE CONNECTOR PROVIDED.
3. RAISE CEILING PAN TO THE CEILING AND CAREFULLY TUCK THE WIRES INSIDE THE OUTLET BOX. SPREAD THE ELECTRICAL SPLICES SO THAT THE BLACK WIRES ARE ON ONE SIDE OF THE OUTLET BOX AND THE WHITE WIRES ARE ON THE OTHER SIDE. PASS SCREWS FROM CROSSBAR THROUGH KEY HOLES IN CEILING PAN. TURN CEILING PAN TO LOCK, TIGHTEN SCREWS.
4. SCREW NIPPLE TO COUPLING ON BOTTOM OF CEILING PAN AND SECURE WITH A NUT.
5. INSTALL A 13 WATT GU24 BASE TYPE "CFS/GU24" BULB (INCLUDED) INTO SOCKET.
6. RAISE GLASS SHADE OVER THE NIPPLE, THEN SECURE WITH METAL WASHER AND NUT.
7. SLIDE FONT OVER END OF THE NIPPLE AND SECURE WITH FINIAL.
8. RESTORE POWER. YOUR NEW FIXTURE IS NOW READY FOR USE.