

HOLSAG CANADA

Seating Manufacturer

Specifications: Spencer Chair and Barstool

Description

The Spencer chair and barstool are economical versions of the ladderback style. These models are lighter weight than those in the Carole line. A limited number of standard finish colors is offered for the Spencer line, making lead times shorter than average.

Dimensions: Chair

Height	30"	76 cm
Depth	17"	43 cm
Seat Width	15"	38 cm
Seat Depth	16"	41 cm
Seat Height	18"	46 cm
Chair Weight	10 lbs	4.5 kg
Carton Weight		
with 1 chair	28 lbs	13 kg
with 2 chairs	45 lbs	21 kg
Carton Size for 1 Chair		
	18.25" x 22.25" x 37.5"	
	46 cm x 56 cm x 95 cm	
Carton Volume for 1 Chair		
	8.8 cubic feet	
Carton Size for 2 Chairs		
	18.25" x 24.5" x 37.5"	
	46 cm x 62 cm x 95 cm	
Carton Volume for 2 Chairs		
	9.7 cubic feet	
<i>Note: Packing of chairs is based on the shipping method.</i>		

The Spencer chair is non-stacking.

Dimensions: Barstool

Height	43"	109 cm
Depth	17"	43 cm
Seat Width	15"	38 cm
Seat Depth	16"	41 cm
Seat Height	30"	76 cm
Stool Weight	24 lbs	11 kg
Carton Weight		
with 1 stool	34 lbs	15.5 kg
Carton Size for 1 Barstool		
	18.5" x 20" x 48"	
	46.3 cm x 50.8 cm x 121.8 cm	

Volume	10.3 cubic feet
--------	-----------------

Note: The barstool is available in custom seat heights ranging from 24" (61 cm) to 30" (76 cm).

The Spencer barstool does not come with kickplates.

Seats are made of beech veneer.

Stock fabric: Black vinyl is available as a stock fabric.

Cushion Foam: High density 1.5" (3.8 cm) thick on seat

Wood

Species: 100% Solid European Beech Hardwood

Construction

Joints: Mortise and tenon.
Glued with high solids glue and reinforced with 18 gauge nails, corner blocks and low root woodscrews.

Stain Colors

A wide range of standard stain colors is available as well as custom color matching. (A surcharge will apply to custom colors.)

9-Step Finishing Process

1. The bare wood of the assembled chair is thoroughly sanded using 120 grit paper.
2. One coat of stain is sprayed onto the entire chair – including the underside of the seat.
3. The stain is handwiped to ensure an even color and maximum penetration into the wood.
4. The chair is inspected and any necessary adjustments made.
5. One coat of a catalyzed sealer is sprayed onto all wood parts to completely seal the wood –

including the underside of the seat.

6. Once dry, the sealer is sanded using 320 grit paper.
7. A final sanding is done using Scotch Brite pads to remove any sanding marks.
8. A catalyzed lacquer is sprayed on. This lacquer is very durable and will stand up in a commercial environment.
9. A final inspection is performed prior to packaging to ensure a high level of quality control.

Note: Specifications are subject to change without notice.

Holsag Canada

164 Needham Street
Lindsay, Ontario Canada
K9V 5R7

(705) 878-1970

(888) 745-0721 (U.S. & Canada)

Fax: (705) 878-1864

www.holsag.com