



ASSEMBLY INSTRUCTIONS




SOUTHERN ENTERPRISES, INC.

BC9310M JCP LOT #778-9807





RELAX....IF YOU CAN FOLLOW A FEW EASY STEP-BY STEP DIRECTIONS IN ORDER, YOU CAN ASSEMBLE THIS ITEM.



HARDWARE IDENTIFICATION

NO.	DRAWING	DESCRIPTION	QTY
1		SCREW	10PCS
2		FLAT WASHERS	10PCS
3		LOCK WASHERS	10PCS
4		ALLEN WRENCH	1PC

PARTS IDENTIFICATION

<p>A</p>  <p>LEG-4PCS</p>	<p>B</p>  <p>HEAD-1PC</p>	<p>C</p>  <p>TAIL-1PC</p>
<p>D</p>  <p>SEAT-1PC</p>		




TURN THE SEAT UPSIDE DOWN. INSERT SCREWS THROUGH PREDRILLED HOLES IN LEGS, HEAD AND TAIL. USING ALLEN WRENCH, TIGHTEN SCREWS INTO PREDRILLED HOLES ON BOTTOM OF SEAT TOGETHER WITH FLAT WASHERS AND LOCK WASHERS. SET STOOL UPRIGHT.

Please count, identify and compare parts and hardware list to be sure all parts are present. It may help to divide parts and label them to correspond with part list. Extra hardware may be included. If any items are missing, please contact our parts/service department at (800)633-5096 or in Dallas (972)869-0111/9am-4pm Mon-Fri central time. Missing or damaged hardware and/or parts will be replaced free of charge. WE DO NOT SELL PARTS.WE DO NOT RECOMMEND MODIFYING PRODUCT(S) AND WE ARE NOT RESPONSIBLE FOR ANY DAMAGES DUE TO PRODUCT MODIFICATION(S). If this product has not been purchased from our retail affiliates(within 9 months).we are under no obligation to provide parts or replacement merchandise. Parts will not be available for items arriving fully assembled.

PARTS REPLACEMENT FORM

STYLE NO.: BC9310M
JCP LOT#778-9807

Customer Name	PARTS LETTER	PART DESCRIPTION	QUANTITY NEEDED
Street, City, State, Zip			
Phone#			
 <p>SOUTHERN ENTERPRISES INC. P.O. Box 59996 Dallas, Texas 75229</p>		Please indicate where you purchased this item. Store/website/catalog	
		/ /	
		Please indicate color/size/style number	
		/ /	