



SOUTHERN ENTERPRISES INC.

STYLE NO. HP0375
JCP LOT NO. 778-5739

RELAX... If you can follow a few easy, step-by-step directions in order, you can assemble this item.

<p>METAL TOP "A" ———</p> <p>METAL TUBE "B" ———</p> <p>UMBRELLA RACK "C" ———</p> <p>BOLT "D" ———</p> <p>WRENCH "E" ———</p>	<p style="text-align: center;">PARTS LIST</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td>(A) METAL TOP</td> <td style="text-align: right;">1PC</td> </tr> <tr> <td>(B) METAL TUBE</td> <td style="text-align: right;">1PC</td> </tr> <tr> <td>(C) UMBRELLA RACK</td> <td style="text-align: right;">1PC</td> </tr> <tr> <td>(D) BOLT</td> <td style="text-align: right;">1PC</td> </tr> <tr> <td>(E) WRENCH</td> <td style="text-align: right;">1PC</td> </tr> </table>	(A) METAL TOP	1PC	(B) METAL TUBE	1PC	(C) UMBRELLA RACK	1PC	(D) BOLT	1PC	(E) WRENCH	1PC
(A) METAL TOP	1PC										
(B) METAL TUBE	1PC										
(C) UMBRELLA RACK	1PC										
(D) BOLT	1PC										
(E) WRENCH	1PC										

STEP:

1. INSERT METAL TUBE "B" TO THE TOP OF UMBRELLA RACK "C" .
2. INSERT THE METAL TOP "A" TO THE METAL TUBE "B" .
3. USING ALLEN WRENCH "E" , TIGHTEN ALLEN BOLT "D" TO SECURE "B" TO "C" .

Please count, identify and compare parts and hardware list to be sure all parts are present. If any items are missing, please contact our parts/service department at (800) 633-5096 or in Dallas(972) 869-0111. Missing or damaged hardware and/or parts will be replaced free of charge.

PARTS REPLACEMENT FORM

STYLE # HP0375
JCP LOT # 778-5739
Customer Name _____

PARTS
LETTER

PART
DESCRIPTION

QUANTITY
NEEDED

Street, City, State, Zip _____

Please indicate where you purchased this item.
Store/website/catalog _____

SOUTHERN ENTERPRISES INC.

P.O. Box 59996
Dallas, Texas 75229

Please indicate color/size/style number _____