

# Easy Installation

---

**Tools Required:** (not included)  
Pliers & Teflon tape

1

Remove existing shower head from shower arm.



2

Attach new head to shower arm. (Teflon tape recommended to prevent leakage.)



For help  
installing,  
call

*Alsons Help Line*

*Toll Free*

*1.800.400.5640*

*8:00am - 7:00 pm*

*Monday - Friday*

*Eastern Time*