



DORCHESTER DAYBED

Model #287-01/287-02

CUSTOMER SERVICE
PHONE NUMBER:
502/ 562-0000
DATE: 04-07-03

IMPORTANT UNLESS OTHERWISE STATED, PLEASE DO NOT TIGHTEN BOLTS (AND/OR) SCREWS UNTIL UNIT IS COMPLETELY ASSEMBLED ON A FLAT SURFACE. Examine all packaging material for small parts that may have come loose during shipment. Periodic checks are recommended to insure that all components are in proper position, tight and free from damage. Keep this assembly instruction for future reference.

HARDWARE LIST	PARTS LIST	
A (8) Long Allen Bolts 5/16" x 3 5/8"	H (1) Back Panel	
B (4) Short Allen Bolts 5/16" x 2 1/8"	J (1) Left Side Panel	
C (8) Spring Washers	K (1) Right Side Panel	
D (12) Metal Washers		
E (8) Rubber Washers		
F (8) Hex Nuts		
G (1) Allen Wrench		

Figure 1

Figure 2

**Bed Frame
* Not Included
as shown in
Figure 2.**

STEP 1
Attach Back Panel (H) to both Left & Right Panels (J & K) using 2 Short Allen Bolts (B) per each side. Tighten All Bolts. See Figure 1.

STEP 2
Attach Bed Frame (*Not Included) to posts on both Left & Right Panels (J & K) using 2 Long Allen Bolts (A), 2 Spring Washers (C), 2 Rubber Washers (E) 2 Metal Washers (D) & 2 Hex Nuts (F) per each post. Tighten All Bolts. See Figure 2. Assembly is now complete.

CARE & MAINTENANCE: The touch of a soft cloth is all the maintenance the finish of your new Daybed will ever need. Never use harsh or abrasive cleaners for polishing. Periodic checks are recommended to make sure that all bolts, screws and nuts are securely tightened.