



**READ ALL INSTRUCTIONS
BEFORE ASSEMBLING LAMP**

Carefully unpack lamp parts onto carpeted surface or blanket and identify all parts. Be sure to place parts in a line that closely resembles assembled lamp. All wires are connected when unpacking. Be careful handling wires during assembly.

1. Thread Center Stem to top of Lamp.
2. Place Shade onto Threaded Socket. Secure Shade by fastening Counter Ring onto Threaded Socket.
3. Install (2) Type B, 60 Watt Max. Candlebra base Bulbs (not included) into Sockets as noted on relamping label at Socket area.
4. Secure finial to top of shade where indicated in illustration.

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit contact a qualified electrician. Never use with a extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.