

## 5-Port In-Wall Diverter Installation Instructions Model No. I-605

Before installation of trim, loosen locknut and all-thread. Cut stem to desired length. Cut all-thread  $\frac{1}{2}$ " shorter than end of stem. Place stem onto valve and rotate between locked positions. Locked positions are when the stem "snaps" into a stationary position (e.g. shower port on). Hand tighten all-thread into valve body. Once all-thread is snug, loosen all-thread  $\frac{1}{16}$  to  $\frac{1}{8}$  of a turn. Tighten locknut on to valve body bonnet while securely holding all-thread in loosen position.

