



INSTALLATION INSTRUCTIONS

1. Before beginning the installation, carefully unpack and identify all parts referring to the illustration.
2. Turn the power to the installation point OFF at circuit breaker.
3. Locate the SHADE HOLDER and match the holes on it with the mounting holes on the BACKPLATE. Secure them by threading the SMALL SCREWS into the mounting holes and tighten until snug.
4. **Make the wiring connections:**
Using wire connectors (not supplied), connect the HOUSE GROUND WIRE to the FIXTURE GROUND WIRE; connect the HOUSE WHITE WIRE to the FIXTURE WHITE (or RIBBED) WIRE; connect the HOUSE BLACK (or RED) WIRE to the FIXTURE BLACK (or SMOOTH) WIRE. Wrap each connection with approved electrical tape.
5. Proceed to secure the BACKPLATE to the wall mounted outlet box by using (2) OUTLET BOX SCREWS (not supplied). Prior to this, determine how many METAL TABS will need to be removed from the backplate in order to align the BACKPLATE with the mounting holes on the outlet box. To remove the METAL TABS, use a flat head screw driver to apply pressure from the backside of the BACKPLATE. Once the METAL TAB moves forward, remove with pliers.
6. Position the SHADE seating onto the SHADE HOLDER. Locate the LOCK SCREW through the hole on the bottom of the SHADE. Proceed to locate the CAP over the end of the LOCK SCREW and thread the FINIAL to secure them together. Be sure the FLAT SIDE of the FINIAL facing the wall.
7. Install bulb referring to fixture markings and/or labels for maximum wattage.
8. Restore the power to the installation point ON. Retain this sheet for future reference.