

DaVinci and Barcelona Library Wall Installation

The connecting together of your library wall cabinets will be easiest if these simple steps are followed.

Removable Plugs

Each cabinet section has four removable pre-finished plugs that are installed on each side. These plugs allow for a finished side panel when another cabinet is not being attached. If you are going to attach two or more cabinets together, these plugs must be removed before making the connection. You can locate the four holes that are plugged from inside the cabinet (2 near the top and two near the base). With a screwdriver, push the plug from inside the cabinet and it will pop out. Find and discard these plugs. If they are left on the floor or between the cabinets, they can prevent the cabinets from forming a tight connection.

Connecting and Aligning the Cabinets

It is easiest to set cabinets (upright) side by side allowing enough space between them for the PIN connector that aligns the ladder rails. Insert the PIN Connector and tighten the set screw with the provided Allen wrench. Once aligned, push the cabinets together by pushing at the bottom of the cabinet side until the cabinets are tight together. The protruding portion of the PIN Connector should fit snugly into the adjoining cabinets' rail. There is no need to install the second set screw in the ladder rail sleeve. The cabinets will be locked together when the four connector bolts are installed. Attach the two top connector bolts without tightening. Align the top crown molding while tightening the top two connector bolts. Once the top moldings are positioned correctly and the top connector bolts are tight, attach the bottom two connector bolts while aligning the base moldings.

Leveling the Cabinets

Once the cabinets are connected and in their final location, place a level on the vertical frame of the cabinets. If you are installing the wall unit on top of carpet it is likely that the wood tack strip used to install carpeting will force the cabinets to be out of alignment. If they lean forward or are out of alignment, there are adjustable levelers in the front corners of each cabinet. They can be adjusted with a medium size standard screwdriver by inserting the tip in the holes in the front corners of the bottom shelf. A clockwise turn will extend the adjustable foot. Have someone push back on the top of the cabinet or apply a wedge as the adjustment is made.

Helpful Hint

To ensure a tight fit between the ladder rails, you may have to loosen the 4 mounting screws, and adjust the 2 ladder poles to fit tightly over the adjoining sleeve.

We hope you receive many years of enjoyment from your Parker House wall cabinets.