

HUTCH ORGANIZER

INSTALLATION INSTRUCTIONS

Illustration 1




Illustration 2





Illustration 3



Read all instructions and review illustrations before installing.

Tools required for assembly:
None

This assembly includes:
(1) Hutch organizer
(4) Plastic glide
(1) CD organizer assembly

Plastic Glide Installation (refer to Illustration 1):

1. Place hutch organizer upside down on a clean work surface.
2. Locate four holes on bottom of hutch organizer.
3. Insert plastic glides into holes as shown and press down firmly.

CD Organizer Assembly Installation:

1. Refer to Illustration 2. Insert a CD case divider into CD organizer as shown. Slide CD case divider rearward until CD case divider locks into place. Repeat this procedure for remaining CD case dividers.

NOTE
If dual CD case storage is desired, do not install CD case dividers.

2. Refer to Illustration 3. Remove protective backing from mounting tape on rear of CD organizer assembly.
3. Refer to Illustration 3. Position CD organizer assembly into either of the larger storage nooks on the hutch organizer.
4. Refer to Illustration 3. With the mounting tape toward the storage nook wall, align edges of the CD organizer with the front edges of the hutch organizer.
5. Refer to Illustration 3. Press CD organizer firmly against storage nook wall.
6. Install remaining CD organizer assembly onto opposite wall of storage nook.

Hutch organizer installation:

1. With plastic glides down, insert hutch organizer into hutch.
2. Position hutch organizer, inside of hutch, as needed.