

## Limited Warranty Information

We warrant this product to be free from defects in material or manufacture at the time of sale and that it will remain serviceable for a period of 90 days from date of purchase. This warranty does not cover damage through misuse, abuse, alteration, unauthorized repairs, accident, or Acts of God.

The preceding warranties are the sole express warranties made by ColdHeat. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF FITNESS AND MERCHANTABILITY, ARE HEREBY LIMITED IN DURATION TO A PERIOD ENDING 90 DAYS FROM THE DATE OF PURCHASE. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

**EXCLUSIVE REMEDY FOR NONCONFORMITY:** If during the warranty period, the product does not conform to the preceding warranties, we will repair or replace the product at our option. We will use new and/or reconditioned parts in repairs or replacements. Following repair, the warranty will continue for the remaining portion of the warranty period.

**THIS IS THE EXCLUSIVE AND SOLE REMEDY FOR ANY BREACH OF WARRANTY.** To obtain warranty service, return the product, postpaid along with the original sales receipt and \$7.95 for postage and handling to:

COLDHEAT CONSUMER PRODUCTS LLC  
1750 112th Ave NE, Suite C-100  
Bellevue, WA 98004

**DISCLAIMER OF INCIDENTAL AND CONSEQUENTIAL DAMAGES:** IN NO EVENT SHALL COLDHEAT, ITS LICENSORS AND/OR ITS MEMBERS, BE LIABLE FOR ANY INCIDENTAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES, WHETHER RESULTING FROM NONDELIVERY OR FROM THE USE, MISUSE, OR INABILITY TO USE THE PRODUCT OR FROM DEFECTS IN THE PRODUCT.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

# COLDHEAT™

## Cordless Heated Seat

Think of it as an oasis of warmth in a cruel, cold world.

- ➊ **Temperature Control:** three controlled settings allow you to find the right temperature from chilly office spaces to frigid winter air and everything in between.
- ➋ **Fabric:** our water resistant, anti-slip material fights against harsh elements while transferring the right amount of heat.
- ➌ **Foam:** dense top-of-the-line polyurethane foam distributes weight evenly.

## Operating Instructions

1. Connect battery pack connector with the seat connector. Insert the battery pack into the foam. Best results will be obtained with a fully charged battery pack. Battery will need to be charged before first operation.
2. Turn on by pushing the main switch (☺). The seat is heated at high temperature setting (▶▶▶) initially.
3. The setting can be adjusted by pressing the temperature setting switch (☺). There are three temperature settings.
4. The warm up time depends on the temperature setting and ambient temperature. For best results, start with high temperature setting for quick heating and switch to medium or low setting for comfort or battery longevity if desired. At high temperature setting, users should feel the sensation of heat in less than 1 min.
5. Low battery charge is signaled by flashing lights. The lights will remain flashing until the battery is totally discharged.
6. If the seat is left unused for more than 8 minutes, it will automatically shut down and all the indicators will be off. To restart the seat, press on the main power switch or the temperature setting switch.
7. Plug battery into charger when battery is discharged or when the seat will not be used for a significant period of time.

## Indicator Lights

Indicator				Flashing Lights	Lights Off
Power Setting	High	Medium	Low	Low Battery	Power is off

## Temperature Settings

The ColdHeat™ Cordless Heated Seat has three temperature settings which are ideal for both outdoor and indoor uses. For fast warm up time, start with high temperature setting and switch to medium or low for outdoor or indoor operation as desired.

Temperature Setting	High	Medium	Low
Recommended for outdoor use	Yes	Yes	No
Recommended for indoor use	Yes	No	Yes
Battery Life (when used in setting continuously)	~ 1.5 hours	~ 3 hours	~ 6 hours

## Charger Operating Instructions

1. Disconnect NiMH battery pack from seat.
2. Connect battery pack to the charger.
3. Plug charger into household electric outlet. The red LED (indicator light) will light up for proper charging.
4. After full charge, the LED indicator turns green. Battery pack will charge in approximately 4 hours; less time is required for a partially discharged battery.
5. Remove charger from power source, then remove battery from charger after full charge.
6. Please allow 2-3 charge cycles to achieve full battery capacity.

## Charger Indicator Lights

Charger LED	Meaning
Red	Charging
Green	Fully Charged
Flashing Red and Green	Allow battery pack to charge. Charger LED will turn Red after 30 minutes. After full charge, LED will turn Green. If LED continues flashing over 1 hour, battery pack must be replaced.

## Washing Instructions

Unzip cover and remove from foam before washing. Machine wash cover with warm water on gentle cycle. Do not use bleach. Line dry; do not tumble dry. Do not iron. Do not place foam in washing machine.



## Safety Instructions

Follow these safety precautions to reduce the risk of personal injury.



- Turn power switch to "Off" when not in use for an extended period of time.
- Children should be supervised if using the seat.
- Do not use the seat as a flotation device.
- Do not charge the seat with a charger directly. Charge removable battery instead.
- Do not store your seat in high-temperature environments as this can damage the batteries, electronics or foam.
- Do not charge other appliances with the ColdHeat Charger.
- Do not charge your ColdHeat™ Cordless Heated Seat with other chargers.

## SAVE THESE INSTRUCTIONS

California Residents: This product contains nickel, a substance known to the state of California to cause cancer.

This Class B digital apparatus complies with Canadian ICES-003.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.