


THE SUPERIOR LENS CLEANING SYSTEM FOR ALL FINE OPTICS

Cameras • Camcorders • Binoculars • Telescopes • And Much More

Lenspen's chamois tip is impregnated with a revolutionary non-liquid cleaning compound that absorbs oily residues and contaminants safer, easier and more effectively than any other method.



a unique cap replenishes the cleaning compound and keeps the tip protected when not in use

a pocket clip lets you attach it to anything and it's compact enough to throw in a pocket or a camera bag

a high quality, all natural retractable brush lets you safely remove dust or hard particles from the lens surface

Wads of tissue, leaky fluid bottles & grimy optical cloths are a thing of the past!

- 1** Extend retractable brush and wipe away any dust or particles of grit.
- 2** Remove cap to expose cleaning tip. Wipe away any smudges with a smooth, circular motion.
- 3** Replace cap and turn half way to replenish the non-liquid cleaning compound.

NOTE: In cases of hardened deposits, breathe lightly on the lens, then wipe off completely with LensPen.

The quality lens cleaning instrument is manufactured in a "clean room" environment to assure that the cleaning tip of LensPen is free of any unwanted hard particles when purchased. For maximum performance and safety to the lens, use LensPen according to instructions provided.

Carson Optical Inc.
1-800-967-8427
info@carson-optical.com