




Assembly Instructions

Frank High



PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer, or fax Euro Style at 415-455-8033.



During assembly, **hand tighten** screws only. When all screws are in place, then tighten completely.