

# euro style™

## Assembly Instructions

### Ida Desk

**PLEASE NOTE:** Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer, or fax Euro Style 415-455-8033. During assembly, hand tighten screws only. When all screws are in place, then tighten completely.

