

WARNING

Failure to follow these warnings and the instructions could result in serious injury or death!

- The crib, including side rails, must be fully erected prior to use.
- Always provide the supervision necessary for the continued safety of your child. When used for play, NEVER leave child unattended.
- Strings can cause strangulation! DO NOT place items with a string around a child's neck such as hood strings or pacifier cords. DO NOT suspend strings over crib or attach strings to toys.
- To reduce the risk of SIDS, pediatricians recommend healthy infants be placed on their back to sleep unless otherwise advised by your physician.
- DO NOT place crib near window where cords from blinds or drapes can strangle a child.
- DO NOT use crib near objects that child could reach or pull into crib and cause injury such as lamps, heaters, fireplaces, or ironing boards.
- When child is able to pull to standing position, remove bumper pads, large toys, and other objects that could serve as steps for climbing out.
- Discontinue use of the crib when child is able to climb out or reaches the height of 35 inches (89 cm). The child should be placed in a youth or regular bed.
- Replace teething rail if damaged, cracked or loose.
- If refinishing, use a non-toxic finish specified for children's products.
- DO NOT use a water mattress with this crib.
- To avoid injuries, do not allow children to climb or play on or under the crib.

WARNING

Infants can suffocate

- In gaps between a mattress too small or too thick and side of crib.
- On soft bedding.
NEVER add a mattress, pillow, comforter or padding.
- Use ONLY the mattress provided by the manufacturer (which must be at least 37-1/2 inches long by 23-1/2 inches wide and not more than 2 inches thick).
- Never use plastic shipping bags or other plastic film as mattress covers not sold and intended for that purpose. They can cause suffocation.

WARNING:

ANY MATTRESS USED IN THIS CRIB MUST BE AT LEAST 37-1/2 INCHES LONG BY 23-1/2 INCHES WIDE WITH A THICKNESS NOT EXCEEDING 2 INCHES.

FOLDING AND STORAGE OF CRIB

⚠️ WARNING

- Prevent serious injury or death, **NEVER** leave child in crib during folding or disassembly.
- Avoid pinching injury. Keep fingers away from hinges during folding of crib.

STEP 1 - MATTRESS

1. Remove Mattress from crib.




STEP 2 - MATTRESS SUPPORT

1. Raise Mattress Support up until it rests against Stationary Side.



STEP 3 - FOLD CRIB

1. While holding Mattress Support against Stationary Side, pull center of Folding End Panels in toward center of crib ①.
2. Slowly pull Stationary Sides together allowing Folding End Panels to continue to fold inward until it is almost into the completely folded position ②.
3. Position mattress in a vertical position and slide it vertically down in between Mattress Support and Folding End Panels.
4. With Mattress in position, finish folding crib by pulling sides together.
5. Secure the folded crib for transport and storage - pull closure straps out through vertical rails, wrap around a rail on Stationary Side, and secure the fabric hook and loop fasteners.



This completes folding the crib.

Crib is ready for storage.

Store crib in a cool, dry location.

OPERATION, MAINTENANCE AND CLEANING

- This crib is guaranteed to meet all federal and state standards and will provide many years of service provided you adhere to the following guidelines for assembly, maintenance and operation.
- Never aim or point a vaporizer or humidifier directly at the crib. The water vapor will ruin the finish of the crib, as it would any other fine piece of furniture.
- For parts or assistance, call Foundations™.

CAUTION: Periodically check the safety of your crib by making certain all screws, nuts, and bolts are tightened securely. Call Foundations™ to replace any broken or missing parts. **DO NOT** substitute parts.

- Your crib may be cleaned using a damp cloth with mild soap or a soft dry cloth.
- Avoid using furniture polish or cleaning agents that may be hazardous to children.
- Replace teething rail if damaged, cracked or loose.
- If refinishing, use only non-toxic finish specified for children's products.
- Set-Up and Folding - see Set-Up Instructions or Folding And Storage Instructions.

ONE YEAR LIMITED WARRANTY

Foundations™ warrants this product to be free from all defects in material and workmanship when used according to the manufacturer's instructions to the original owner for a period of one year from date of purchase. The warranty does not apply to damage caused by product alteration, normal wear and tear, misuse or abuse of the product. Keep your sales receipt as a record of the date of purchase. For replacement parts or warranty issues, please contact Foundations™ as we are better able to serve you. **DO NOT** return the product to your retailer or distributor.

If you need assistance, call or write:
Foundations™, P.O. Box 1910, Medina, OH 44258-1910
Telephone 1-866-740-0195, Fax 1-330-721-6799