



Volcano FIRESTARTER

NO MORE LIGHTER FLUID!




Convenient

Easy

Safe

- Light any type of fire
- Clean
- Odorless
- Waterproof
- Burns up to 10 minutes
- No dripping
- Non-Toxic
- No smoke
- No taste of lighter fluid
- Not hazardous



**Charcoal
Grills**



**Indoor
Fireplaces**



**Outdoor
Fireplaces**




Campfires

GAMASONIC USA INC. • 1 GLENLAKE PARKWAY • SUITE 700 • ATLANTA, GA 30328
TEL (678) 638 6217 • FAX (678) 638 6218 • ITAY@GAMASONIC.COM
WWW.GAMASONIC.COM



Volcano FIRESTARTER



- Do not open the sealed packets
- Place 1 or 2 packets in charcoal or under logs
- Light the sealed plastic packet with a lighter or match
- Let the fire starters burn out completely before cooking

Retail pack	12 pc box
UPC #	094922777638
Case pack	48
Case dimensions	22+1/8" x 8+7/8" x 9+1/4"
Case weight	12.5 lbs
Cases per pallet	48

Retail pack	24 pc box
UPC #	094922777621
Case pack	24
Case dimensions	22+1/8" x 8+7/8" x 9+1/4"
Case weight	12.5 lbs
Cases per pallet	48



Charcoal Grills Indoor Fireplaces Outdoor Fireplaces Campfires

Your #1 Fire Starting Solution!

Preferred by MILLIONS of customers around the world

Volcano FIRE STARTER

- Clean
- Easy
- Safe
- Oderless
- Waterproof
- Non-Toxic

24 PACK

GAMASONIC USA INC. • 1 GLENLAKE PARKWAY • SUITE 700 • ATLANTA, GA 30328
 TEL (678) 638 6217 • FAX (678) 638 6218 • ITAY@GAMASONIC.COM
 WWW.GAMASONIC.COM