








# ASSEMBLY INSTRUCTIONS

## 28033/28034 RECTANGULAR DINING TABLE

### Component parts

NO.	HARDWARE (DESCRIPTION)	Q'TY
A	ALLEN WRENCH 5MM 	1
B	ALLEN HEAD BOLT DIA5/16*2-3/4"LONG 	8
C	SPRING WASHER 5/16 	8
D	FLAT WASHER 5/16 X 3/4 O.D. 	8
1	TOP 	1
2	LEG 	4
3	EXTENSION LEAF 	1

- STEP 1: Position Table Top upside down on a soft surface such as carpet or a blanket.
- STEP 2: Attach the four Legs in the corners using two Allen Head Bolts with Spring Washers and Flat Washers. Tighten all bolts using the Allen Wrench.
- STEP 3: Using two persons, carefully turn table upright and move to desired location. Install Leaf if desired.

