






ASSEMBLY INSTRUCTIONS


31021 Round Dining Table

Component List:

- 1) Top with metal apron.....1 pc
- 2) Leg & Stretcher.....2 pcs

Hardware List:

#	HARDWARE	SKETCH	QTY	EXT
A	M5/16" Nut		9 PCS	1PC
B	M5/16" Spring Washer		9 PCS	1PC
C	M5/16" Flat Washer		9 PCS	1PC
D	M5/16" Hex Wrench		1 PC	
E	M5/16" Finial With Bolt		1 PC	



Note: Read instructions thoroughly before attempting to assemble the table.

- 1) Place the Top face down on carpet or a padded surface.
- 2) Attach the Leg & Stretchers and Top together at the aprons and underneath the center of the Top as shown with (A,B,C) but do not fully tighten until after next step.
- 3) Attach the Stretchers together at the center using the Finial with Bolt (E) and with (A,B,C) as shown. Use the Hex Wrench (D) to tighten all nuts.
- 4) Carefully turn the table upright.