







Parts Breakdown

LS1013FL

| <u>Fig #</u> | <u>Part ID</u> | <u>Part Name</u> | <u>Quantity</u> |
|--------------|----------------|----------------------------------|-----------------|
| 1 | 265995-6 | TAPPING SCREW 4X18, 4323K | 2 |
| 2 | 416075-3 | REAR COVER, LS1013 | 1 |
| 3 | 265995-6 | TAPPING SCREW 4X18, 4323K | 1 |
| 4 | 631218-8 | CONTROLLER, LS1013 | 1 |
| 6 | 911373-5 | P.H. SCREW M6X50, LS1013 | 4 |
| 7 | 154719-4 | MOTOR HOUSING CPL., LS1013L | 1 |
| 8 | 181047-4 | CARBON BRUSH SET 154,5402A | 1 |
| 9 | 643650-4 | BRUSH HOLDER CAP 6.5-13.5, 5402A | 2 |
| 10 | 863030-0 | NAME PLATE, LS1013FL | 1 |
| 11 | 596141-3 | FIELD ASS'Y 115V, LS1013 | 1 |
| 12 | 266029-8 | T. SCREW FLANGE PT 5X65, JR3020 | 2 |
| 13 | 416107-6 | BAFFLE PLATE, LS1013 | 1 |
| 14 | 211061-7 | B. BEARING 6000LLB, 6222DWE | 1 |
| 15 | 681642-5 | INSULATION WASHER, LS1013 | 1 |
| 16 | 516926-1 | ARMATURE ASS'Y, LS1013L | 1 |
| 17 | 240001-8 | FAN 80, LS1013F | 1 |
| 18 | 911223-4 | P.H. SCREW M5X16, 4301BV | 2 |
| 19 | 285686-3 | BEARING RETAINER 94, LS1013 | 1 |
| 20 | 211275-8 | BALL BEARING 6003DDW, LS1013 | 1 |
| 21 | 961057-5 | RETAINING RING S-17, 2711 | 1 |
| 22 | 231928-3 | RING SPRING 8, LS1013 | 1 |
| 23 | 256633-1 | PIN 6, LS1013 | 1 |
| 24 | 231240-1 | COMP. SPRING 7, 2414B | 1 |
| 25 | 961018-5 | STOP RING E-5, LS1011 | 1 |
| 26 | 253804-1 | F. WASHER 6, 6012HDW | 1 |
| 27 | 257163-5 | RING 6, LS1011 | 1 |
| 28 | 345604-4 | LINK PLATE, LS1013L | 1 |
| 29 | 922331-6 | H.S.H. BOLT M6X20, LS1013 | 1 |
| 30 | 253804-1 | F. WASHER 6, 6012HDW | 1 |
| 31 | 257163-5 | RING 6, LS1011 | 1 |
| 32 | 344464-1 | SPRING HOLDER, LS1013 | 1 |
| 33 | 233461-1 | COMPRESSION SPRING 28, LS1013L | 1 |
| 46 | 153523-8 | SWITCH BOX CPL., LS1013FL | 1 |
| 47 | 651522-9 | SWITCH SLE6A, LS1013L | 1 |
| 48 | 411478-6 | SWITCH BUTTON, LS1011 | 1 |
| 49 | 183980-6 | HANDLE SET, LS1013L | 1 |
| 50 | 682505-8 | CORD GUARD, 2711 | 1 |
| 51 | 664463-0 | CORD (2X14X8 SJ), 2414B | 1 |
| 52 | 687052-4 | STRAIN RELIEF, HM1500B | 1 |
| 53 | 265995-6 | TAPPING SCREW 4X18, 4323K | 2 |
| 54 | 414546-4 | CAM, LS1011 | 1 |
| 55 | 416000-4 | LOCK OFF LEVER, LS1040 | 1 |
| 58 | 231457-6 | COMP. SPRING 3, HR2400 | 1 |
| 60 | 631576-2 | POWER SUPPLY CIRCUIT, LS1013L | 1 |
| 61 | 651923-1 | SWITCH, LS1211 | 1 |
| 63 | 415999-0 | SWITCH LEVER, LS1040 | 1 |
| 64 | 265995-6 | TAPPING SCREW 4X18, 4323K | 8 |
| 65 | 183980-6 | HANDLE SET, LS1013L | 1 |
| 66 | 921467-8 | HEX BOLT M8X45, LS1013 | 1 |
| 67 | 262003-4 | RUBBER RING 6, LS1013 | 1 |
| 68 | 911323-0 | P.H. SCREW M6X16, LS1211 | 1 |
| 69 | 421562-9 | GRIP, LS1013 | 1 |
| 70 | 344420-1 | GRIP HOLDER, LS1013 | 1 |
| 71 | 911323-0 | P.H. SCREW M6X16, LS1211 | 1 |
| 72 | 911114-9 | P.H. SCREW M4X10, 2012 | 1 |
| 73 | 419277-0 | DUST NOZZLE, LS1013 | 1 |
| 74 | 213460-9 | O RING 35, HM1500 | 1 |
| 75 | 911113-1 | P.H. SCREW M4X10, 4301BV | 1 |
| 76 | 265717-4 | SCREW M6X43, LS1211 | 1 |
| 77 | 262001-8 | RING 5, 6906 | 1 |



Parts Breakdown

LS1013FL

| | | | |
|-----|----------|-------------------------------------|---|
| 78 | 317176-9 | STOPPER ARM, LS1212 | 1 |
| 79 | 819214-8 | MAKITA LOGO LABEL, LS1013L | 1 |
| 80 | 344045-1 | STOPPER ARM PLATE, LS1211 | 1 |
| 81 | 421952-6 | CUSION, LS1013L | 1 |
| 82 | 211021-9 | BALL BEARING 607LLB, LS1013 | 1 |
| 83 | 961054-1 | RETAINING RING S-14, 6302 | 1 |
| 84 | 226742-0 | SPIRAL BEVEL GEAR 33, LS1013 | 1 |
| 85 | 262074-1 | RUBBER RING 20, LS1013 | 1 |
| 86 | 267035-6 | F. WASHER 14, 6805BV | 1 |
| 87 | 213673-2 | O RING 52, 9561CV | 1 |
| 88 | 316836-0 | HOUSING W/O BEARING, (A) LS1013 | 1 |
| 89 | 254202-2 | KEY 4, 9924DB | 1 |
| 90 | 322899-6 | SPINDLE, LS1013 | 1 |
| 91 | 211275-8 | BALL BEARING 6003DDW, LS1013 | 1 |
| 92 | 285828-9 | BEARING RETAINER 66, LS1211 | 1 |
| 93 | 257060-5 | RING 15.88,LS1013 | 1 |
| 94 | 911223-4 | P.H. SCREW M5X16, 4301BV | 2 |
| 95 | 224333-1 | FLANGE 53, LS1040 | 1 |
| 97 | 224333-1 | FLANGE 53, LS1040 | 1 |
| 98 | 265355-2 | H. F. H. BOLT, LS1030 | 1 |
| 99 | 344473-0 | CENTER PLATE, LS1212 | 1 |
| 100 | 345603-6 | CENTER COVER, LS1013L | 1 |
| 101 | 265324-3 | H.F.H. BOLT M8X12, LS1030 | 1 |
| 102 | 265008-3 | SCREW M5, LS1011 | 1 |
| 103 | 231613-8 | T. SPRING 45, LS1211 | 1 |
| 104 | 419073-6 | SAFETY COVER, LS1013L | 1 |
| 105 | 253977-0 | F. WASHER 6, LS1011 | 1 |
| 106 | 911218-7 | P.H. SCREW M5X14, DA6300 | 1 |
| 107 | 421916-0 | GUARD, LS1013L | 1 |
| 108 | 345610-9 | GUARD PLATE, LS1013L | 1 |
| 109 | 188026-3 | BLADE CASE SET, LS1013L | 1 |
| 110 | 266026-4 | TAPPING SCREW 4X12,9046 | 1 |
| 111 | 419078-6 | LEAD COVER HOLDER, LS1013L | 1 |
| 112 | 419076-0 | LEAD COVER, LS1013L | 1 |
| 113 | 418104-8 | LENS, LS1013L | 1 |
| 114 | 804293-9 | LASER LABEL, LS1013FL | 1 |
| 115 | 266306-8 | SHOULDER SCREW M5, LA1013L | 1 |
| 116 | 266229-0 | HEX.SCREW M5X8, 4200N | 2 |
| 117 | 419379-2 | BLOCK C, LS1013FL | 1 |
| 118 | 266318-1 | HEX. SOCKET SET SCREW M4X6, LS1013L | 1 |
| 119 | 231664-1 | TORSION SPRING 9, LA1013L | 1 |
| 120 | 911003-8 | P.H. SCREW M3X6, 9207SPC | 1 |
| 121 | 419378-4 | BLOCK B, LS1013FL | 1 |
| 122 | 911003-8 | P.H. SCREW M3X6, 9207SPC | 1 |
| 123 | 231664-1 | TORSION SPRING 9, LA1013L | 1 |
| 124 | 266318-1 | HEX. SOCKET SET SCREW M4X6, LS1013L | 1 |
| 125 | 638442-4 | LASER CIRCUIT CPL.,LS1013FL | 1 |
| 126 | 419380-7 | TOP COVER, LS1013FL | 1 |
| 127 | 253807-5 | F. WASHER 5, 6012HDW | 1 |
| 128 | 265753-0 | THUMB SCREW M5X24, LS1013L | 1 |
| 129 | 266042-6 | TAPPING SCREW BIND CT 4X20, 9046 | 2 |
| 130 | 331428-4 | PIPE, LS1211 | 1 |
| 131 | 252105-4 | HEX LOCK NUT M8-13, HM1800 | 1 |
| 132 | 941201-0 | F. WASHER 8, 5037NB | 1 |
| 133 | 154779-6 | ARM CPL., LS1013L | 1 |
| 134 | 687095-6 | STRAIN RELIEF, LS1220 | 1 |
| 135 | 266026-4 | TAPPING SCREW 4X12,9046 | 1 |
| 136 | 322317-4 | STOPPER PIN, LS1040 | 1 |
| 137 | 213021-5 | O RING 5, LS1030 | 1 |
| 139 | 251961-9 | H.S.H. SCREW M6X10, LS1040 | 1 |
| 140 | 265371-4 | HEX BOLT M8X30, LS1011 | 2 |



Parts Breakdown

LS1013FL

| | | | |
|-----|----------|-------------------------------------|---|
| 141 | 265412-6 | HEX. BOLT M8X20, LS1013 | 2 |
| 142 | 216003-6 | STEEL BALL 10, 2401B, LS1013 | 2 |
| 143 | 345418-1 | GUIDE PLATE, LS1013 | 1 |
| 144 | 231626-9 | TORSION SPRING 28, LS1013 | 1 |
| 145 | 413067-3 | INDICATION PLATE, LS1013 | 2 |
| 146 | 911114-9 | P.H. SCREW M4X10, 2012 | 2 |
| 147 | 233168-9 | COMPRESSION SPRING 5, LS1013 | 2 |
| 148 | 266131-7 | HEX SOCKET HEAD BOLT M12X12, LS1013 | 2 |
| 149 | 151459-5 | ARM HOLDER COMPLETE, LS1013 | 1 |
| 150 | 251668-7 | HEX. BOLT M10X90, LS1013 | 1 |
| 151 | 911113-1 | P.H. SCREW M4X10, 4301BV | 1 |
| 152 | 416006-2 | LEVER 100, LS1040 | 1 |
| 153 | 252144-4 | HEX. NUT M10-17, LS1013 | 1 |
| 154 | 253024-7 | F. WASHER 10, LS0714 | 1 |
| 155 | 231266-3 | COMP. SPRING 5, LS711DWBEK | 1 |
| 156 | 152542-1 | SQUARE ROD COMPLETE, LS1013 | 1 |
| 157 | 921356-7 | HEX BOLT M6X35, LS1013 | 2 |
| 158 | 153832-5 | TURN BASE CPLT., LS1013 | 1 |
| 159 | 152540-5 | BEARING BOX B COMPLETE, LS1013 | 1 |
| 160 | 922451-6 | H.S.H. BOLT M8X30, LS1013 | 2 |
| 161 | 253852-0 | F. WASHER 8, LS1211 | 1 |
| 162 | 265442-7 | HEX BOLT M8X40, LS1013 | 1 |
| 163 | 419222-5 | KERF BOARD, LS1013L | 2 |
| 164 | 266026-4 | TAPPING SCREW 4X12,9046 | 4 |
| 165 | 911108-4 | P.H. SCREW M4X8, LS1013 | 1 |
| 166 | 252014-7 | HEX LOCK NUT M6-10, LS1040 | 1 |
| 167 | 344463-3 | SUB FENCE PLATE, LS1013 | 1 |
| 168 | 150710-0 | SUB FENCE COMPLETE, LS1013 | 1 |
| 169 | 921451-3 | HEX BOLT M8X30, LS1011 | 4 |
| 170 | 316840-9 | GUIDE RULE, LS1013 | 1 |
| 171 | 912357-6 | C.S.H. SCREW M6X35, LS1013 | 1 |
| 172 | 253715-0 | F. WASHER 6, NHP1310 | 1 |
| 173 | 251887-5 | SCREW M6X10, LS1030 | 1 |
| 174 | 266026-4 | TAPPING SCREW 4X12,9046 | 2 |
| 175 | 816326-8 | MITER SCALE PLATE, LS1013 | 1 |
| 176 | 266132-5 | SCREW M8X320, LS1013 | 1 |
| 177 | 931402-8 | HEX NUT M8, 5037NB | 1 |
| 178 | 271314-6 | KNOB 40, LS1212 | 1 |
| 179 | 941201-0 | F. WASHER 8, 5037NB | 1 |
| 180 | 152541-3 | KNOB 48 COMPLETE, LS1013 | 1 |
| 181 | 331491-7 | PIPE 9-200, LS1013 | 1 |
| 182 | 421563-7 | CAP 10, LS1013 | 1 |
| 183 | 322924-3 | COIL SPRING, LS1013 | 1 |
| 184 | 322909-9 | LOCK PIN, LS1013 | 1 |
| 185 | 253804-1 | F. WASHER 6, 6012HDW | 1 |
| 186 | 231307-5 | COMP. SPRING 6, LS1013 | 1 |
| 187 | 961018-5 | STOP RING E-5, LS1011 | 1 |
| 188 | 316899-6 | PIN HOLDER, LS1013 | 1 |
| 189 | 266034-5 | TAPPING SCREW 4X16, 9524NB | 2 |
| 190 | 344411-2 | SLIDE STOPPER, LS1013 | 1 |
| 191 | 251267-5 | P.H. SCREW M6, LS1013 | 1 |
| 192 | 256196-7 | PIN 5, LS1013 | 1 |
| 193 | 331493-3 | TURN STOPPER, LS1013 | 1 |
| 194 | 344412-0 | STOPPER HOLDER, LS1013 | 1 |
| 195 | 266034-5 | TAPPING SCREW 4X16, 9524NB | 1 |
| 196 | 266026-4 | TAPPING SCREW 4X12,9046 | 1 |
| 197 | 816128-2 | POINTER, LS1013 | 1 |
| 198 | 344477-2 | SLIDE PLATE, LS1013 | 2 |
| 199 | 266034-5 | TAPPING SCREW 4X16, 9524NB | 1 |
| 200 | 232075-3 | LEAF SPRING, LS1011 | 1 |
| 201 | 251887-5 | SCREW M6X10, LS1030 | 2 |



Parts Breakdown

LS1013FL

| | | | |
|-------|----------|-----------------------------|---|
| 202 | 153833-3 | BASE CPL., LS1013 | 1 |
| 203 | 286212-1 | CAP 20, LS1011 | 4 |
| 210 | 941202-8 | F. WASHER 8, 5037NB | 4 |
| 211 | 266048-4 | T. SCREW 4X40, 4334DWD | 2 |
| 212 | 125337-5 | LIGHT ASS'Y, LS1013FL | 1 |
| 213 | 233471-8 | COMP. SPRING 6, LS1013FL | 1 |
| 1,001 | 122523-9 | DUST BAG, LS1040 | 1 |
| 1,002 | 122538-6 | VERTICAL VISE ASS'Y, LS1013 | 1 |
| 1,003 | 411478-6 | SWITCH BUTTON, LS1011 | 2 |
| 1,004 | 762001-3 | TRIANGLE RULE, LS1011 | 1 |
| 1,005 | 783208-8 | HEX WRENCH 2.5, 2012NB | 1 |
| 1,006 | 322932-4 | HOLDER 255, LS1013 | 2 |
| 1,007 | A-93550 | 10 CT SAW BLADE,70T,LS1013L | 1 |
| 1,008 | 782212-4 | SOCKET WRENCH 13, LS1011 | 1 |
| 5,001 | 810268-8 | N/A | 1 |