



**IMPORTANT**  
**TURN OFF THE POWER AT THE MAIN FUSE**  
**OR CIRCUIT BREAKER BOX**  
**BEFORE STARTING INSTALLATION**

Carefully unpack and identify all parts before assembly. Bulb not included.

1. Carefully thread fixture wire and ground wire through fixture loop. Screw fixture loop onto top threaded pipe until secure.
2. Install top column securely onto top of central column.
3. Install central column securely onto top of Fixture body.
4. Install font and finial by screwing onto bottom of fixture.
5. Place Shade onto Threaded Socket. Secure Shade by fastening Spacer Tube and Counter Ring onto Threaded Socket.
6. Install (9) Type A, 100 Watt Max. medium base bulbs (not included) into Sockets as noted on relamping label at Socket area.

**CHAIN HUNG INSTALLATION:**

- A. Carefully thread the fixture wires through fixture loop.
  - B. This fixture is supplied with 2 threaded chain links. These links are opened and closed by twisting cylinder on chain link. One threaded chain link should be installed onto canopy loop and the other should be installed onto fixture loop. The standard chain should be installed in between these 2 threaded chain links.
  - C. Determine the desired length of chain to hang. Remove any unwanted links with chain plier.
  - D. Take ground wire and weave through above chain links, then thread through hole in canopy loop. Repeat with fixture wire (wire with plastic insulation).
7. Follow enclosed "**Multiple Standard Installation Instructions**" for electrical and fixture installation onto ceiling outlet box.

**Note:** Before starting wire connection, enlist a helper to support the fixture, or make a hook from a wire coat hanger and temporarily suspend the fixture from mounting plate.