

ASSEMBLY INSTRUCTIONS FOR YOUR

MULTI - FACETED
TALL TABLE LAMP

ASSEMBLY INSTRUCTIONS

1. Remove all products from carton. Remove all packaging material from lamp.
2. Place base (E) on level surface.
3. Insert harp (C) into harp saddle (D) by squeezing both sides of harp (C) inward and placing onto the harp saddle (D).
4. Remove finial (A) from harp (C). Place center ring of shade spider (located inside shade (B)) onto threaded nipple of harp (C). Thread finial (A) onto threaded nipple of harp (C) to secure shade (B) to harp (C).
5. Install one (1) Type A, 100 watt maximum bulb into socket.
6. Remove protective plastic (G) from electrical plug (F).
7. Insert electrical plug (F) lamp into wall outlet.

Care Instructions: To clean, use soft cloth only. Do not use any chemical or abrasive cleaners.

Note: Turn the power off (unplug from the wall outlet) before replacing the bulb, making sure the bulb has had sufficient time to cool down. Do not subject the lamp to any shock while lit as shattering of bulb may result.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce risk of electric shock, this plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted.

DO NOT ALTER THE PLUG.

