

Features and Operating Instructions

No Adjustment Necessary



Flex Back

Sit back and the Flex Back supports you and responds to your multidimensional movements.



Flex Top

Simply rest your arms comfortably over the top of the Flex Back.



Flex Seat

Sit in any position—forward, sideways or perched—and the Flex Seat supports you with 270° of seat edge flex.



Dynamic Suspension control

The synchronized recline counterbalances your body weight for a smooth and effortless ride. Four independent flexors act as suspension devices that respond to your multidirectional movements—forward, backward and side-to-side.

Intuitive Adjustments (Standard)



Seat height

Lift the right front lever. Sit down to lower the seat or remove your weight to raise it. Release the lever to lock.



Seat depth


While seated, lift the left lever and slide the seat to the desired position. Release the lever to lock.



Tilt preference selector

Select the degree of recline movement for your preference and your task. Sit fully upright. Rotate the back right lever until it clicks into one of three positions—all the way back for the most movement, in the middle for less, or all the way forward for greater upright support.

Performance Options




Arm options

Cantilevered arm supports provide clearance for your legs and feature Continuous Lumbar, so your back is supported when side sitting.




Height adjustable arm

To adjust the height, lift the lever on the arm and lift the arm to disengage. Slide the arm to the desired position and release the lever to lock.



High performance arm

To adjust the height, lift the lever on the arm and lift the arm to disengage. Slide the arm to the desired position and release the lever to lock. Free float arm pads move easily in width and depth, and pivot.



Height adjustable lumbar

Grasp both sides of the lumbar support and slide it to the desired position.