


à la carte™ synchro-tilt



1 Pneumatic seat height

To raise chair, lift body weight up and pull lever up. To lower chair, remain seated and pull lever up.

2 Tilt tension

To decrease tension, turn counterclockwise. To increase tension, turn clockwise.

3 Upright back lock

To lock back in upright position, lean forward and push lever back.

To release back lock, lean forward and push lever forward.

4 Back height

Grab chair back with both hands and slowly pull up to desired height. To lower back, pull up to highest position, and back will drop to lowest position.

Reset mechanism by pushing down firmly, then adjust upward.

5 Seat depth via back

Loosen bolt and adjust back in or out to desired position. Retighten bolt.

6 Arm height

Squeeze trigger under outside of arm cap and raise or lower arm to desired height. Release trigger.

7 Maintenance arm width

Loosen screws under arm bracket, adjust arm in or out, tighten screws.

note: your chair may not have all the adjustments shown.