


AT-2567

ASSEMBLY INSTRUCTIONS



Bell'O International Corp.
711 Ginesi Drive
Morganville, NJ 07751-1235
Customer Service: (888) 235-7646
E-mail: support@bello.com
Web: www.bello.com

1 x		Ordering part # CHFE 007 Sheet nr. ALLEN KEY
6 x		Ordering part # PEFE 142 Sheet nr. 12
6 x		Ordering part # GMPL 036 Sheet nr. 13
4 x		Ordering part # VTAC 174 Item nr. 5
2 x		Ordering part # VTAC 026 Item nr. 7
4 x		Ordering part # FVPL 005 Item nr. 15
2 x		Ordering part # PDPL 029 Item nr. 9
4 x		Ordering part # PDPL 021 Item nr. 10
1 x		Ordering part # MHAF 030 Item # 17



Note: Two people are recommended to assemble this unit ON A SOFT SURFACE.

REMOVE the two side panels (1a) and (1b) from the carton and place them upright, (with the TOP sticker towards the top of the panels) on a SOFT FLAT SURFACE about 2 feet apart with the threaded inserts for the glass support pins (12) facing inwards towards each other.

NOTE: The TOP frame (2b) and the BOTTOM frame (2a) are NOT identical. The BOTTOM frame (2a) can be identified by a small adjustable foot (17) located on the center underside of the BOTTOM frame. The SIDE PANELS (1a) and (1b) are the same and ARE interchangeable.

POSITION the TOP frame (2b) over the side panels (1a) and (1b), with the hole (3) used to attach the CMS® (Cable Management System) post facing towards the back and the larger openings of the TOP frame treaded inserts (4) facing upwards as shown in Fig. 2. TO AVOID SCRATCHING THE TOP FRAME, GENTLY INSERT the TOP frame (2b) into the cut-outs on the top of the side panels (1a) and (1b), and SECURE the TOP frame to the side panels using two of the long bolts (5) and the supplied Allen key. DO NOT TIGHTEN FULLY AT THIS POINT.

CAREFULLY TURN the partially assembled furniture upside down and PLACE it ON A SOFT SURFACE so that it is resting on the TOP frame (2b), with the open ends of the panels facing upwards. REPEAT the same assembly from above for the BOTTOM frame (2a). DO NOT TIGHTEN FULLY AT THIS POINT.

CAREFULLY TURN the partially assembled furniture back over again so that it is resting on the BOTTOM frame (2a). POSITION the CMS® (Cable Management System) post (6) against the rear of the furniture, with the TOP sticker at the top, and the CLOSED side facing towards the front. ALIGN the screw holes in the CMS® with the holes (3) located in the rear of TOP and BOTTOM frames (2b) and (2a). ATTACH the CMS® post to the frames with two short bolts (7) and the supplied Allen key, as shown in Fig. 1.

NOW GO BACK AND FULLY TIGHTEN ALL BOLTS.

MOVE the tower to the location that it will occupy in the room when fully assembled and in use.

INSERT the four plastic caps (8) onto the open ends of both side panels (1a) and (1b). PLACE two large rubber pads (9) onto the top frame (2b) as shown in Fig. 1.

SCREW the six shelf support pins (12) into the threaded holes located on the inside of the side panels (1a) and (1b) and fasten securely. PLACE the plastic covers (13) over the six shelf support pins (12).

PLACE four small glass pads (10) onto the upper edge of the bottom frame (2a) as shown in Fig. 1. CAREFULLY SLIDE one of the four smaller glass shelves (11) onto the bottom frame with the small hole facing toward the rear, and INSERT the shelf through the slot of the CMS® post (6). LOCK the glass shelf in place by CAREFULLY INSERTING the supplied "T" shaped shelf locking pin (15) into the hole (14) at the rear of the shelf as shown in Fig.3.

CAREFULLY SLIDE the remaining three smaller glass shelves (11) onto the shelf support pins (12) with the small hole facing toward the rear and INSERT the shelves through the slots of the CMS® post (6). LOCK the glass shelves in place by CAREFULLY INSERTING the supplied "T" shaped shelf locking pin (15) into the hole (14) at the rear of the shelves as shown in Fig.3.

CAREFULLY CENTER and PLACE the top glass shelf (16) over the top frame (2b), with the curved edge facing forward.

IMPORTANT NOTE: WHEN IN USE, THIS FURNITURE MUST BE PLACED ON A FLAT AND LEVEL SURFACE. ADJUST THE FRONT LEVELING FOOT (17) UNTIL THE FURNITURE RESTS SQUARELY ON THE FLOOR.

IMPORTANT: REMOVE ALL GLASS, AND OTHER EQUIPMENT FROM THE FURNITURE PRIOR TO MOVING THE ASSEMBLED FURNITURE. DO NOT ATTEMPT TO MOVE THE ASSEMBLED FURNITURE AFTER THE GLASS SHELVES HAVE BEEN INSTALLED, AND/OR WHEN THERE IS EQUIPMENT LOCATED ON THE FURNITURE AS THIS MAY CAUSE THE SHELVES TO BECOME UNSECURE AND FALL. WHEN IN USE, THIS FURNITURE MUST BE PLACED ON A FLAT AND LEVEL SURFACE.

ALWAYS PLACE THE HEAVIEST EQUIPMENT ON THE BOTTOM SHELF.