

MODEL: 50128

## ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

### UNPACK THE FOUNTAIN

TO PROTECT THE FINISH, PLACE ALL PARTS ON A SOFT SURFACE. YOU SHOULD HAVE RECEIVED THE FOLLOWING: LIGHT ASSEMBLY WITH (2) SCREWS AND (2) HALOGEN BULBS, TRANSFORMER, FOUNTAIN BODY, SPLASHGUARD, SUBMERSIBLE PUMP.

### FOUNTAIN ASSEMBLY

1. ATTACH LIGHT ASSEMBLY TO REAR PANEL OF FOUNTAIN. (SEE IMAGE BELOW)
2. ATTACH RUBBER PUMP HOSE TO PUMP AND PLACE PUMP FLAT IN RESERVOIR AND
3. INSTALL A MR-16 BULB BY SLIPPING INTO PLACE AND TIGHTENING SCREWS. (TWO BULBS ARE PROVIDED, PLEASE RETAIN SECOND HALOGEN BULB FOR FUTURE BULB REPLACEMENT.)
4. MEASURE DISTANCE FROM FLOOR TO BRACKET ON BACK OF FOUNTAIN.
5. PLACE HOOK OR NAIL (NOT INCLUDED, CHOOSE AN ATTACHMENT MECHANISM APPROPRIATE FOR YOUR WALL) IN WALL AND SECURE FOUNTAIN TO WALL BY PLACING HOOK OR NAIL IN BRACKET.
6. JOIN THE LIGHT CONNECTORS TOGETHER.
7. ATTACH SPLASHGUARD TO EDGE OF RESERVOIR.
8. FILL RESERVOIR WITH ENOUGH WATER TO COMPLETELY SUBMERSE PUMP. (DISTILLED WATER IS RECOMMENDED BY US TO REDUCE MINERAL DEPOSITS AND BACTERIA BUILD UP.)
9. PLUG THE TRANSFORMER AND PUMP POWER CORD INTO SOCKETS.
10. TURN ON AT SWITCH, YOUR FOUNTAIN IS READY TO USE.

### TROUBLE SHOOTING:

1. IF YOUR FOUNTAIN DOES NOT WORK, CHECK PLUG AT THE SOCKET. MAKE SURE THE PLUG IS FULLY AND PROPERLY INSERTED INTO THE WALL OUTLET.
2. NEXT CHECK TO MAKE SURE THE OUTLET IS POWERED.
3. IF THE FOUNTAIN STILL DOES NOT WORK, PLEASE CONTACT YOUR DISTRIBUTOR OR PLACE OF PURCHASE.

### SPLASHING DISCLAIMER:

SPLASHING MAY OCCUR WHEN FOUNTAIN IS INITIALLY TURNED ON. PROTECT SURROUNDING SURFACES AS NEEDED.

### IMPORTANT PUMP INFORMATION:

PUMP MUST BE FULLY SUBMERSED IN WATER WHILE OPERATING.

### WATER:


TO REDUCE MINERAL DEPOSITS AND BACTERIA BUILD UP THE USE OF DISTILLED WATER IS RECOMMENDED.

### IMPORTANT SAFETY INSTRUCTIONS:

THIS FOUNTAIN IS RATED FOR INDOOR USE ONLY.


### WARNING:

ONCE A WEEK INSPECT FOUNTAIN, FLOOR AND ADJACENT WALL FOR MOISTURE BUILD-UP AND CLEAN AS NECESSARY. THIS IS ESPECIALLY IMPORTANT FOR HUMID ENVIRONMENTS.



FRONT VIEW

REAR VIEW



MOUNT THE LIGHT