

**FIXTURE TOP VIEW**

AVAILABLE PARTS ARE:  
80491GSCH (GLASS SHADE)  
BULBGU10 (BULB)

**MODEL: 80495CH**  
**ASSEMBLY INSTRUCTIONS**  
**READ AND SAVE THESE INSTRUCTIONS**

**TOOLS:** YOU WILL NEED THE FOLLOWING TOOLS OR EQUIPMENT: LADDER, SCREWDRIVER, DRILL AND WIRE CUTTERS.

**UNPACK THE FIXTURE**

YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS IN THE PACKAGE: CANOPY, (4) CAPS, (4) SOCKET ASSEMBLIES, (8) SET SCREWS, (4) GLASS SHADES, WRENCH AND (8) BULBS. TO PROTECT THE FINISH, PLACE ALL PARTS ON A SOFT SURFACE.

**MOUNTING HARDWARE PACKAGE:**

(4) 8-32 X 1-1/4" SCREWS, (2) NUTS, MOUNTING PLATE, GREEN GROUND SCREW, (3) WIRE CONNECTORS, (2) PLASTIC ANCHORS, (2) WOOD SCREWS AND (2) FINIALS.

**FIXTURE ASSEMBLY**


1. DETERMINE THE LENGTH OF CORDS REQUIRED TO HANG THE FIXTURE AT THE DESIRED HEIGHT, ADJUST THE CORDS BY UNSCREWING (4) SET SCREWS NEAR CANOPY, THEN SECURE THE CORDS TO CANOPY BY TIGHTENING THE (4) SET SCREW.

**\*\*STOP\*\* COMPLETE INSTALLATION INSTRUCTIONS ON NEXT PAGE BEFORE CONTINUING TO FINAL ASSEMBLY.**

**FINAL ASSEMBLY**

1. SLIDE A CAP OVER EACH MALE CONNECTOR AND PLACE A GLASS SHADE OVER EACH SOCKET ASSEMBLY.
2. JOIN THE MALE CONNECTORS AND FEMALE CONNECTORS TOGETHER.
3. SCREW THE CAPS TO TOP OF SOCKET ASSEMBLIES AND TIGHTEN (4) SET SCREWS. (WRENCH INCLUDED)
4. INSTALL A 35 WATT MAX. GU10 BULB (INCLUDED) INTO EACH SOCKET.
5. RESTORE POWER, YOUR NEW FIXTURE IS NOW READY FOR USE.





## INSTALLATION INSTRUCTIONS

**READ AND SAVE THESE INSTRUCTIONS**

### CAUTION

TO AVOID POSSIBLE ELECTRIC SHOCK, MAKE SURE THE ELECTRICITY IS SHUT OFF AT THE MAIN PANEL. IF YOU ARE REPLACING AN EXISTING FIXTURE, FIRSTLY, TURN THE FIXTURE OFF. NEXT, TURN THE WALL SWITCH OFF. FINALLY, GO TO THE MAIN FUSE OR BREAKER BOX IN YOUR HOME. TURN THE FUSE OR BREAKER TO THE OFF POSITION. SOME TYPES OF FUSES MUST BE UNSCREWED TO SHUT OFF THE POWER.

\* ALL WIRING MUST BE DONE IN ACCORDANCE WITH NATIONAL AND LOCAL ELECTRIC CODES.

\*\* IF YOU DO NOT HAVE ELECTRICAL WIRING EXPERIENCE, HAVE YOUR FIXTURE INSTALLED BY A QUALIFIED LICENSED ELECTRICIAN.

\*\*\* THIS FIXTURE IS TO BE MOUNTED TO A UL LISTED OUTLET BOX CAPABLE OF SUPPORTING THE WEIGHT OF THIS FIXTURE. THE OUTLET BOX MUST BE DIRECTLY SUPPORTED BY THE BUILDING STRUCTURE.

### INSTALL THE FIXTURE:

1. LIFT MOUNTING PLATE TO OUTLET BOX SO THAT THE SCREW HOLES IN OUTLET BOX LINE UP WITH SLOTS ON MOUNTING PLATE. MARK SPOTS AT OUTER HOLES FOR THE PLASTIC ANCHORS TO BE INSTALLED.
2. DRILL PILOT HOLES ON THE MARKED SPOTS AND INSERT PLASTIC ANCHORS. (IF FASTENING WITH WOOD SCREWS TO STUD, IGNORE THIS STEP)
3. ATTACH MOUNTING PLATE TO CEILING OUTLET BOX USING TWO SCREWS PROVIDED WITH THE OUTLET BOX. (NOTE: IF THE SCREWS WITH THE OUTLET BOX ARE TOO SHORT, USE THE (2) 8-32 x 1-1/4" SCREWS PROVIDED IN THE MOUNTING HARDWARE PACKAGE).
4. ATTACH ENDS OF MOUNTING PLATE TO THE PLASTIC ANCHORS OR THE SPOTS THAT YOU MARKED ON STUD AND SECURE WITH (2) WOOD SCREWS.
5. CONNECT THE WHITE OR RIBBED FIXTURE WIRE TO THE WHITE SUPPLY WIRE IN THE OUTLET BOX USING THE TWIST-ON WIRE CONNECTOR PROVIDED. CONNECT THE BLACK OR SMOOTH FIXTURE WIRE TO THE BLACK SUPPLY WIRE IN THE SAME MANNER. INSTALL THE FIXTURE GROUND WIRE UNDER THE GREEN GROUND SCREW ON THE MOUNTING PLATE THEN CONNECT THE FIXTURE GROUND WIRE TO THE SUPPLY GROUND WIRE IN THE OUTLET BOX USING THE TWIST-ON WIRE CONNECTOR PROVIDED.
6. TUCK THE CORDS CAREFULLY INSIDE THE CANOPY, NEXT RAISE THE CANOPY TO THE CEILING AND SECURE IN PLACE WITH (2) FINIALS.
7. SEE PREVIOUS PAGE FOR FINAL ASSEMBLY INSTRUCTIONS.

